



SECRET
Premium Pond Products
★★★★★

Secret Lumora
Basic & Premium
single and set



FOR YOUR SAFETY

Read and understand this manual before use
Keep this manual for future reference



INDEX

Nederlands

Veiligheidsinstructies	3
Technische parameters	4
Installatie en onderhoud	4
Problemen oplossen	4
Garantie	4

English

Safety instructions	5
Technical Parameter	5
Installation and maintenance	6
Troubleshooting	6
Warranty	6



Nederlands

Lees de gebruiksaanwijzing en maak uzelf vertrouwd met de apparatuur voordat u deze in gebruik neemt. Correct en veilig gebruik van het systeem vereist strikte naleving van de veiligheidsinstructies. Om veiligheidsredenen mogen kinderen en jongeren onder de 16 jaar, evenals personen die potentiële gevaren niet kunnen herkennen, of personen die niet bekend zijn met deze instructies, dit apparaat niet gebruiken.

Veiligheidsinstructies

Als er schade is aan de apparatuur, kan deze niet meer worden gebruikt. Deze apparatuur is niet bedoeld voor gebruik door een persoon (inclusief kinderen) met verminderde fysieke, sensorische of mentale vermogens, of een gebrek aan ervaring en kennis, tenzij zij toezicht of instructies hebben gekregen over het gebruik van de apparatuur door een persoon die verantwoordelijk is voor hun veiligheid. De apparatuur moet buiten bereik van kinderen worden geplaatst. Om veiligheidsredenen mogen personen jonger dan 16 jaar en personen die geen gevaar kunnen herkennen of de instructies niet kunnen begrijpen, de apparatuur niet gebruiken.

1. Neem bij problemen altijd contact op met een elektricien.
2. Trek vóór elke handeling de stekker uit het stopcontact.
3. Alleen gebruiken met een geaard stopcontact en lekstroombeveiliging.
4. Gebruik geen beschadigde adapters of verlengkabels.
5. Gebruik een lekbeveiliging (RCD) ≤ 30 mA.
6. Elektrische installaties in tuinen moeten voldoen aan nationale normen.
7. Controleer of spanning en frequentie overeenkomen met het etiket.
8. Houd de stekker en verbindingen droog.
9. Bij schade aan kabel of behuizing mag de LED niet worden gebruikt.
10. Beschadigde kabels mogen enkel door professionals worden vervangen.
11. Gebruik deze verlichting nooit voor vloeistoffen anders dan water.
12. Alleen te gebruiken bij een watertemperatuur tussen: -10 °C + 35 °C

Product kenmerken

1. Geschikt voor vijvers , fonteinen, beeklopen en watervallen
2. Energiezuinig en toch krachtig!
3. De lamp heeft een waterdichte transformator voor externe voeding. De lage spanning verhoogt de veiligheid.
4. Geschikt voor verlichting boven en onder water in vijvers.
5. Wordt geleverd met beugels en klemmen voor flexibele montage.
6. Kan optioneel worden uitgerust met een grondpen voor plaatsing in verschillende soorten ondergrond



Technische parameters

Model	Verbruik	Kabel lengte	Lichthoek	Transformator
Secret Lumora Basic 1	1x 1 watt	5 meter	120 graden	DC12V 3.6W
Secret Basic 2	2x 1 watt	5 meter	120 graden	DC12V 3.6W
Secret Basic 3	3x 1 watt	5 meter	120 graden	DC12V 3.6W
Secret Lumora Premium 1	1x 3 watt	5 meter	30 graden	220/240V-50Hz
Secret Lumora Premium 2	2x 3 watt	5 meter	30 graden	220/240V-50Hz
Secret Lumora Premium 3	3x 3 watt	5 meter	30 graden	220/240V-50Hz

Installatie en onderhoud

Schakel de stroom uit wanneer u de binnenkant schoonmaakt. Neem bij het schoonmaken van de binnenkant de bovenstaande onderdelenlijst als referentie.

INSTALLATIE

1. Lees de veiligheidsinstructies.
2. Controleer de spanning en frequentie van het stopcontact.
3. Plaats de pomp in het water en zorg dat deze stevig staat.
4. Plaats de kabel zodat deze niet beschadigd raakt, nooit doorknippen en verbinden.

Problemen oplossen

Probleem	Reden	Oplossing
Lamp gaat niet aan	<ul style="list-style-type: none">• Geen stroom• Lamp defect	<ul style="list-style-type: none">• Stekker aansluiten• Vervang de lamp

Garantie

1. De garantietermijn bedraagt 2 jaar, geldig vanaf de datum van de verkoopfactuur (tevens de aankoopdatum).
2. Schade die is veroorzaakt door verkeerd gebruik is uitgesloten van garantie.
3. Maximale vergoeding overschrijdt nooit de productwaarde



English

Read the operating instructions and familiarize yourself with the equipment before putting it into operation. Correct and safe use of the system requires strict compliance with the safety instructions. For safety reasons, children and young people under the age of 16, as well as persons who cannot recognize potential hazards or persons who are not familiar with these instructions, must not use this device.

Safety Instructions

If the equipment is damaged, it may no longer be used. This equipment is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction regarding the use of the equipment by a person responsible for their safety. The equipment must be kept out of reach of children. For safety reasons, persons under 16 years of age and persons who cannot identify hazards or do not understand the instructions may not use the equipment.

1. Always contact an electrician if any problems occur.
2. Always unplug the device before carrying out any work.
3. Use only with a grounded outlet and residual-current protection.
4. Do not use damaged adapters or extension cords.
5. Use a residual current device (RCD) with ≤ 30 mA sensitivity.
6. Electrical installations in gardens must comply with national standards.
7. Check whether the voltage and frequency match the specifications on the label.
8. Keep the plug and all connections dry.
9. If the cable or housing is damaged, the LED must not be used.
10. Damaged cables may only be replaced by qualified professionals.
11. Never use this pump for any liquids other than water.
12. Applicable environmental temperature: -10 °C + 35 °C

Product Features

1. Suitable for fountains and pumps.
2. Energy-efficient yet powerful!
3. Light color is 3000K

Technical parameters

Model	Power	Cable length	Angle of beam	Transformer
-------	-------	--------------	---------------	-------------



Secret Lumora Basic 1	1x 1 watt	5 meter	120 graden	DC12V 3.6W
Secret Basic 2	2x 1 watt	5 meter	120 graden	DC12V 3.6W
Secret Basic 3	3x 1 watt	5 meter	120 graden	DC12V 3.6W
Secret Lumora Premium 1	1x 3 watt	5 meter	30 graden	220/240V-50Hz
Secret Lumora Premium 2	2x 3 watt	5 meter	30 graden	220/240V-50Hz
Secret Lumora Premium 3	3x 3 watt	5 meter	30 graden	220/240V-50Hz

Installation and Maintenance

Switch off the power when cleaning the inside of the unit. When cleaning internal components, refer to the parts list above..

INSTALLATION

1. Read the safety instructions.
2. Check the voltage and frequency of the power outlet.
3. Position the cable to prevent damage; never cut or reconnect the cable.

Troubleshooting

Problem	Cause	Remedy
Light does not turn on	<ul style="list-style-type: none"> • No power • Lamp broken 	<ul style="list-style-type: none"> • Check electrical circuit • Replace lamp

WARRANTY

1. The warranty period is 2 years, valid from the date of the sales invoice (which also serves as the purchase date).
2. Damage caused by improper use is excluded from the warranty.
3. The maximum compensation will never exceed the value of the product.

